

Inside Window Recess

1.



To fit the blind inside the window recess, begin by measuring the width of the recess at the top of the window using a steel tape measure for accuracy.

2.



The next step is to measure the drop of the recess. To do so, measure at the left, centre and right as shown in the picture. Note the shortest measurement.

3.

When ordering your blinds, you must remember to specify them as 'Recess Measurement' to ensure you receive the correct size. Our experts at Kingston Blinds will make a 10mm deduction from the width and drop measurements provided to ensure your blinds fit inside the window recess perfectly.

Important

Never measure existing blinds that you may have in your window when ordering a complete new blind, measure the window as if it's a blank canvas.